



## Star Toolholders Ø22



Ordering Code Right Hand		D	L	L1	F	Insert Screw	Anvil Screw	Torx Key	RH Anvil	LH Anvil
<b>SER 0022 H11</b>	11	22	100	40	13.3	S11	-	K11	-	-
<b>SER 0022 H16</b>	16	22	100	40	14.6	S16	A16	K16	AE16	AI16

For **LEFT HAND** toolholders specify **SEL** instead of **SER**

## Product Identification

### Threading Toolholders Ordering Codes

